

## Congratulations on choosing MAS product.

Before installing this product, read and follow the warning notices and instructions.

### 1. WARNING INSTRUCTIONS:

- \* Please do not bend the power cable excessively or it may cause an electric shock.
- \* Please do not handle the connector with a wet hand.
- \* Please do not install the product in the place where there is much oil smoke or humidity.
- \* Please do not use and connect this product with other products with different rated voltage.

### 2. OVERVIEW:



### 3. USAGE:

#### 3.1. ANSWERING COMING CALLS:

The flat can be called from 3 different caller type ( security, entrance panel, flat door):

1. When you receive a call from Target A or Target B, the assigned doorbell melody will be rang. If there is a camera at Target A or Target B, you can get the caller's view. ( the view on the screen will stay open for 60 seconds.)
2. When you receive a call from the entrance panel, you can get the caller's view automatically, by means of the panel camera. ( the view on the screen will stay open for 60 seconds. )
3. When you receive a call from in front of the flat door , by means of an installed extra camera in front of the flat, you can see who is the visitor behind the flat door. ( optional ) Answering the call is up to you. If you want to answer the call, you should press the (  ) button. Unless you want to answer the call, there is no need to press any button.

#### 3.1.1 PUSH TO TALK (PTT) MODE:

When you receive a call from the entrance panel/security point, the screen is opened and stay open for 45 seconds. When you press&hold the (  ) button, you can start talking to the caller/dialler for 60 seconds. When you stop holding the (  ) button, you can start listening for 15 seconds. When you are away from your home or when you don't want to answer the call, the LED blinks. In this time, you can press any button to stop blinking. While you are speaking with the caller/dialler, you can get the views coming from the extra cameras by pressing the (  ) button.

#### 3.1.2. HANDSFREE MODE:

Basically once you press the (  ) button to speak with the caller/dialler. When you receive a call from the entrance panel or the security point, the screen is opened and stay open for 45 seconds. Within this time, you should press the (  ) button to start talking to the caller for 60 seconds. If you want to end the call earlier than 60 seconds, you should press again the (  ) button. When you are away from your home or when you don't answer the call, the LED blinks. It means that there is an/ some unanswered call(s). When you see this warning, you can press any button to stop blinking.

#### 3.2 OPENING DOOR:

If you want to open the door , you should press the (  ) button. ( It is also possible to open the door while you are speaking with the panel.)

#### 3.3 CALLING SECURITY/GUARD:

You can call the assigned target ( security or guard) by pressing button A or button B. The dialler ( security ) can see your flat & block number on its own unit/security phone screen.

#### 3.4 WARNING LED INDICATOR ( RED, GREEN OR CLOSED ):

When you call someone or when the screen is open, the LED lights up in green. It means that the caller's line is busy. If you don't answer the coming call , the LED in red blinks. It means that there is an/some unanswered call(s). If the LED is not lighting up in any color, it means that the line is ready to call / to be called.

#### 3.5 OPENING THE SCREEN / CHANGING THE CAMERA:

You can open the screen by pressing the (  ) button and you can get the view coming from the entrance panel. If more than one camera integrated to the system, you can see the other views coming from the other cameras by pressing the (  ) button one by one.

#### 4. DEVICE SETTINGS:

##### 4.1 SPEAKING MODE (HANDSFREE / PUSH TO TALK) SELECTION:

When you want to change the speaking mode, you should press&hold the (  ) button and (  ) button for 5 seconds. You can realize the speaking mode that has been switched when the LED starts blinking.

##### 4.2 DOORBELL MELODY SELECTION:

You can define 3 melodies in 10 melodies to the several communication points. (coming calls from security, guard, front of the flat, panel) By pressing & holding button (  ) and button A until hearing the warning beep , you can start to change the doorbell melody. You can listen all the melodies by pressing button A. When you decide to choose a melody, please follow the steps as below.

##### To change the melody of coming calls from the panel:

If pressed button (  ) once, the melody will be chosen and to save it please press the button A. To exit the menu , press the button B.

##### To change the melody of coming calls from the front of the flat:

If pressed button (  ) twice, the melody will be chosen and to save it please press the button A. To exit the menu , press the button B.

##### To change the melody of coming calls from Target A:

If pressed button (  ) three times, the melody will be chosen and to save it please press the button A. To exit the menu , press the button B.

##### To change the melody of coming calls from Target B:

If pressed button (  ) four times, the melody will be chosen and to save it please press the button A. To exit the menu , press the button B.

##### 4.3. Default settings

By pressing & holding (  ) and button B for 10 seconds you will hear warning beep, it means that the system has been switched to the default settings.

##### 4.4. SCREEN LIGHT, DOORBELL VOLUME LEVEL AND PANEL VOLUME LEVEL ADJUSTMENTS:

All the adjustments are made in the factory. If required, screen light adjustment , doorbell volume level adjustment, panel volume level adjustment can be made from the back of the unit by using a screwdriver.



AVAILABLE IN 4 COLOR !